

## Product Data Sheet SORB<sup>®</sup>XT Safety-Kit

Article	SORB <sup>®</sup> XT Safety-Kit
Article No.	100500EN
Dimensions (mm)	400x300x70
Weight	0,70 Kg
Absorption capacity	2,60 L



## Product Information:

### Recommended use

- 2L sachet: Mobile first aid for smaller leakages
- Barrier pillow: On usual grounds and on water as a barrier and absorbent

### Application

- spread out SORB<sup>®</sup>XT evenly over the leaked substance and work into the material
- place the pillows directly on the area of contamination and wait until it has reached its full absorptive capacity (the pillow will be entirely in the color of contaminated material)
- the pillow can be applied on all mentioned fields plus on water surfaces

### Storage

- store in an dry place with low humidity to avoid mold

### After application

- skim off or sweep up the substance from the surface
- collect the substance with pick-up spatula and put it into a disposal bag/ collect the pillow with single-use gloves and put it into a disposal bag
- dispose of the contaminated material following the respective valid laws and local regulations

### Properties

- ideal combination for small leakages, contains the following:
- 1x 2L Sachet of 100% organic SORB<sup>®</sup>XT fibre
- 1x Barrier pillow (filled with 100% organic SORB<sup>®</sup>XT fibre)
- 1x Single-use gloves
- 2x Disposal bag